

*fidata*

HFAS1-S10U  
Network Audio Server

## Setup Guide



Before reading this Setup Guide, please be sure to look at “Quick Guide” and “Conformity Information and Warranty”.



# Table of Contents

<b>1. Composition of the Instruction Manual</b> .....	<b>3</b>
<b>2. Getting More out of this Unit</b> .....	<b>4</b>
2.1. Open the Settings Screen .....	5
2.2. Saving Audio Files from a USB HDD .....	6
2.3. Streaming Music on a USB HDD as it is .....	10
2.4. Confirming the Amount of Free Space .....	12
2.5. Adjusting the Brightness and Colour of the Front Indicator .....	13
2.6. Not turning on the LAN Port indicator .....	15
2.7. Backing Up Music .....	17
2.8. Switching the Mode of the Built-in Disk (RAID) .....	22
2.9. Setting the Time Zone .....	25
2.10. Keeping the Firmware/Software of this Unit up to Date .....	27
<b>3. Details of the Settings screen</b> .....	<b>29</b>
3.1. HOME .....	30
3.2. SYSTEM INFORMATION .....	31
3.3. SYSTEM SETTINGS .....	33
3.4. USB DEVICE SETTINGS .....	38
3.5. DISK MANAGEMENT .....	39
3.6. SYSTEM INITIALIZATION .....	40
3.7. FIRMWARE UPDATE .....	41
<b>4. Troubleshooting</b> .....	<b>42</b>

# 1. Composition of the Instruction Manual

The instruction manual of this unit includes the following.

- **Quick Guide:**

Describes the basic way to use this unit.

- **Conformity Information and Warranty:**

Provides guidance on the warranty and standards of this unit and contact information.

- **Setup Guide (this document):**

Describes detailed settings to this unit.

- **Twonky Server Reference:**

Describes the Twonky Server that is employed in this unit.

You can download these instruction manuals from the following website

<http://www.iodata.jp/fidata/en/support/#download>



## 2. Getting More out of this Unit

<a href="#">2.1. Open the Settings Screen</a>	5
<a href="#">2.2. Saving Audio Files from a USB HDD</a>	6
<a href="#">2.3. Streaming Music on a USB HDD as it is</a>	10
<a href="#">2.4. Confirming the Amount of Free Space</a>	12
<a href="#">2.5. Adjusting the Brightness and Colour of the Front Indicator</a>	13
<a href="#">2.6. Not turning on the LAN Port indicator</a>	15
<a href="#">2.7. Backing Up Music</a>	17
<a href="#">2.8. Switching the Mode of the Built-in Disk (RAID)</a>	22
<a href="#">2.9. Setting the Time Zone</a>	25
<a href="#">2.10. Keeping the Firmware/Software of this Unit up to Date</a>	27

## 2.1. Open the Settings Screen

Open the Settings screen to make various settings in this unit.

For details of the operations to perform after you open the Settings screen, please see [\[2. Getting More out of this Unit\] \(page 4\)](#) or [\[3. Details of the Settings screen\] \(page 29\)](#).

### 1 Install the settings tool "Magical Finder".

Computer

<http://www.iodata.jp/foodata/en/support/#download>


iOS/Android

Search for "Magical Finder" in the App Store or Google Play Store.

### 2 Start "Magical Finder".

\* Connect the personal computer or terminal on which settings are to be made to the same router as the one used by this unit.

### 3



Click [browser]

↓  
The settings screen opens.

**The message [Because the IP setting is not correctly done, the setting screen cannot be correctly opened by a browser. Please set an IP address.] is displayed.**

(1) Click [OK] to close that screen.

(2) Click [IP settings].

(3) Set so that it is the same network as the one that the computer or terminal on which settings are performed is connected to.

\* If the IP address is a AAA.BBB.CCC.DDD, please set up to AAA.BBB.CCC, the same as the computer or terminal, and set DDD to between 0 and 255 while making sure that it is not the same as other devices.

Please set subnet mask and default gateway to the same value as they are on the computer or terminal. (In Magical Finder on a computer, the computer network settings are displayed on the same screen.)

## 2.2. Saving Audio Files from a USB HDD

By connecting and operating a USB HDD that contains audio files, you can copy them to this unit.

### 2.2.1. Copying Audio Files to a USB HDD

Please copy audio files from a computer or such like to a USB HDD.

#### Get audio files ready.

You can get audio files by downloading from a music distribution site or ripping them from a music CD. For details of the supported formats of audio files, please see the Quick Guide.

#### [Important] As a precaution, please back up data regularly.

A sudden failure could corrupt any saved audio files and lead to a loss of data. For details of this unit's backup function, please see "[2.7. Backing Up Music \(page 17\)](#)".

### 2.2.2. Saving Audio Files from a USB HDD


- 1 Connect a USB HDD to a USB port on the back of this unit.

#### Using a multi-port card reader.

If you use a multi-port card reader instead of a USB HDD, please insert only one piece of media.


- 2 [2.1. Open the Settings Screen](#)

- 3



Click [USB DEVICE SETTINGS]

4




Click [Data import]




Click [NEXT]

5



Click [IMPORT]

6




Click [Yes]



The front indicator flashes.

**Caution: Do not remove the USB HDD**  
If you click [Yes], audio files start to be copied and the front indicator flashes. Please do not remove the USB HDD while the front indicator is flashing.

7



Confirm that the front indicator is lit.



Remove the USB HDD.




This completes the operation.

## 2.2.3. Removing the USB HDD

If you want to remove a USB HDD when the power to this unit is on, please do so with the following operation.


### 1 [2.1. Open the Settings Screen](#)

2



Click [USB DEVICE SETTINGS]

3




Click [Removal of the USB device]



Click [NEXT]



4




**When two USB HDD units are connected.**

When you are using a USB hub, and a USB HDD for shared use and a USB HDD for backup use are connected, choose one to remove, and then click [REMOVE].

Click [REMOVE]

5



Confirm that the message [Remove completed.] is displayed.



Remove the USB HDD



This completes the operation.

## 2.3. Streaming Music on a USB HDD as it is

---

By connecting a USB HDD that contains audio files to this unit and operating it, you can stream the music on the USB HDD as if it were saved on this unit.

### 2.3.1. Copying Audio Files to a USB HDD

---

Please copy audio files from a computer or such like to a USB HDD.

#### **Get audio files ready.**

You can get audio files by downloading from a music distribution site or ripping them from a music CD. For details of the supported formats of audio files, please see the Quick Guide.

#### **[Important] As a precaution, please back up data regularly.**

A sudden failure could corrupt any saved audio files and lead to a loss of data.  
It should be noted that this unit's backup function will not backup the music stored on the USB HDD.

### 2.3.2. Streaming Music on a USB HDD as it is

---

**1** Connect a USB HDD to a USB port at the back.

**2** Confirm that the front indicator has gone from flashing to lit.



You are now able to stream the music on the USB HDD as if it were saved on this unit.

#### **Using a computer to confirm the audio files on the USB HDD that is connected to this unit.**

While referring to "Saving Audio Files" in the Quick Guide, access this unit from a computer.

There is a [usb1] folder in the same place as the [contents] folder. The files in this folder are the audio files on the USB HDD.

\* The [usb1] folder is read-only in order to protect the music (you cannot write to it or delete files in it).

**Using a USB hub and two USB HDD units.**

If you use a USB hub, you can connect two USB HDD units, one for shared use and one for backup use.

- \* We recommend a type of USB HDD that is connected to an electrical outlet for most types of USB hub.
- \* Even if you connect two or more USB HDD units for the same application (for shared use / for backup use), you will not be able to use them.
- \* For details of the backup function, please see "[2.7. Backing Up Music \(page 17\)](#)".

### **2.3.3. Removing the USB HDD**


---

If you want to remove a USB HDD when the power to this unit is on, please do so with the following operation [2.2.3. Removing the USB HDD \(page 8\)](#).

## 2.4. Confirming the Amount of Free Space

### 1 [2.1. Open the Settings Screen](#)


2



Click

[SYSTEM INFORMATION] opens.

3



Confirm the amount of free space on this unit (Internal disk) or a USB HDD (USB disk).

#### When the amount of free space is low

Please delete any unwanted music.

\* Please back up music to your computer or another HDD unit.


## 2.5. Adjusting the Brightness and Colour of the Front Indicator

You can adjust the brightness of the indicator which is mounted on the front of this unit in four stages.

It is set to the brightest setting at the time of purchase. In addition, you can choose white or blue for the front indicator colour.


### 1 [2.1. Open the Settings Screen](#)

2




Click [SYSTEM SETTINGS]

3




Adjust [Front Indicator Brightness]

4




Adjust [Front Indicator Color]

5



Click [CONFIRM]

6




This confirms the settings.

Click [SET]

Please wait for a while until the setting has finished.

7



The front indicator flashes.



Confirm that the front indicator is lit.

This completes the setting.


## 2.6. Not turning on the LAN Port indicator

You can set it so that the LAN port indicator installed on this unit does not light up.

### 1 [2.1. Open the Settings Screen](#)



5



The front indicator flashes.



Confirm that the front indicator is lit.



This completes the setting.




## 2.7. Backing Up Music

You can back up the music that was put on this unit to a connected USB HDD.

\* The music stored on the USB HDD is not backed up.

### 2.7.1 Backing Up

#### First, get a USB HDD ready for backup purposes



#### Automatically backing up data

Any change to the music stored on this unit will be reflected in the automatic backup.

##### Add music

Music is backed up to a USB HDD for backup.

##### Is the music that is already stored on the USB HDD backed up?

After registering a USB HDD for backup, back up data.

##### Deleting music

Music stored on a USB HDD for backup is not deleted.

##### Do I need to always have a USB HDD for backup use connected?

No. Each time you connect it, any music that has been added is backed up.

#### From time to time, please organize the music on the USB HDD for backup.

If you repeatedly add and remove music, the capacity of the USB HDD for backup will be reduced. Please see [\[Using a computer to confirm the music on the USB HDD for backup use.\] \(page 19\)](#) and delete any unwanted music.

When the USB HDD for backup is full, the front indicator lights up in red, and you will not be able to backup to it any more.



## 2.7.2. Registering the USB HDD as a backup one

- 1 Connect a USB HDD that has the same capacity as this unit, or larger, to a USB port on the back of this unit.


**Please connect only one USB HDD.**

A USB HDD for backup is registered as one for backup use, and any data on it will be deleted. So that you do not make a mistake and lose any important data, please only connect one USB HDD with this operation.

- 2 [2.1. Open the Settings Screen](#)



5




Read the Caution items.



Click [REGISTRATION]


6




Click [Yes]



Please wait until the USB HDD is registered.



7



Confirm that the message [Succeeded to register the device for backup.] is displayed.



This completes the operation. The USB HDD has been registered as one for backup use. From now, the music will be backed up on the USB HDD.

**Using a computer to confirm the music on the USB HDD for backup use.**

While referring to "Saving Audio Files" in the Quick Guide, access this unit from a computer. There is a [bkup] folder in the same place as the [contents] folder. This is the music on the USB HDD.

**Using a USB hub and two USB HDD units.**

If you use a USB hub, you can connect two USB HDD units, one for shared use and one for backup use.

- \* We recommend a type of USB HDD that is connected to an electrical outlet for most types of USB hub.
- \* Even if you connect two or more USB HDD units for the same application (for shared use / for backup use), you will not be able to use them.
- \* Please see [2.3. Streaming Music on a USB HDD as it is \(page 10\)](#) for details of how to share a USB HDD.

**Removing the USB HDD.**

Please see [2.2.3. Removing the USB HDD \(page 8\)](#).



If you reconnect a USB HDD for backup to this unit, it automatically starts backing up music.

If you do not want to always connect a USB HDD for backup, we recommend that you connect it occasionally to back up your music.


## 2.7.3. Restoring Music from a USB HDD for Backup

1 Connect a USB HDD for backup to a USB port on the back of this unit.

2 [2.1. Open the Settings Screen](#)



5




Read the Caution items.



Click [RESTORE]

6




Click [Yes]



The front indicator flashes.

7



Confirm that the front indicator is lit.



Remove the USB HDD.



This completes the operation.

## 2.8. Switching the Mode of the Built-in Disk (RAID)

The two internal disks that are installed in this unit operate in several modes (RAID mode). By switching the mode, you can increase the capacity that can be utilized or duplicate music.

However, you will need to format (initialize) the built-in disk in accordance with the mode, and so if you switch the mode then the music on this unit will be lost.

### 2.8.1 Modes

This unit supports three modes.

Mode	Spanning	Striping	Mirroring
Available capacity <sup>*1</sup>	Very good	Very good	Good
Safety of music <sup>*2</sup>	—	—	Very good
Read/write speed <sup>*3</sup>	Good	Very good	Good

\*1 With mirroring, music is written on each of the two internal disks, and so the available capacity will be that of one built-in disk. Therefore, if mirroring is currently set then switching to another mode will double the capacity available for use.

\*2 With mirroring, music is written on each of the two internal disks, and so you will not lose any music even in the unlikely event that one disk fails.

(Our repair center handles requests for replacing the internal disk. Note that the music will be lost if both of the built-in disks have failed.)

\*3 With striping, music is written on the two internal disks by being distributed over them, and so the read and write speed is faster.

#### Confirming the current mode.

You can see the [RAID mode] in [3.2. SYSTEM INFORMATION](#) here.

Note that the mode at the time of purchase is as shown below.

Product Number	Mode	Available capacity
HFAS1-S10U	Spanning	1 terabyte

### 2.8.2. Backing Up before Switching

When you switch the mode, the music on this unit will be lost.





Therefore, please use a USB HDD and back up the music on this unit.

>> [2.7.2. Registering the USB HDD as a backup one](#)


18

## 2.8.3. Switching the Mode of the Built-in Disk

### 1 [2.1. Open the Settings Screen](#)




6



Please wait for a while when this screen is displayed.

7



Click.



The mode of the internal disk has been switched.

**If you switch the mode to mirroring.**

You can use this unit, but it will take a while until the music is duplicated. Please see [RAID status] in [3.2. SYSTEM INFORMATION](#) for the state of duplication. [Rebuilding: ●% complete] is displayed, and then the operation is finished when [Normal] is displayed.

## 2.8.4. Returning Backed Up Music to this Unit

Please use a backed up USB HDD and return the music to this unit.

>> [2.7.3. Restoring Music from a USB HDD for Backup](#)

20




## 2.9. Setting the Time Zone

Set the time zone (standard time zone) of the clock of this unit.

Usually, you do not need to change this, but if you would like to change the time stamp of the music data stored on this item then please set it.


### 1 [2.1. Open the Settings Screen](#)

2




Click [SYSTEM SETTINGS]

3




Set [Time Zone] to the area you live in.

4



Click [CONFIRM]

5



This confirms the settings.



Click [SET]



Please wait for a while until the setting has finished.

## 2.10. Keeping the Firmware/Software of this Unit up to Date

Update the firmware (internal software) of this unit, and keep it up to date.

### 2.10.1. Updating with the Automatic Update Function


When this unit can be updated, the front indicator is lit in orange.

In this state, this unit will be updated to the latest state when you turn off the power to it.

### 2.10.2. Updating Manually


#### 1 [2.1. Open the Settings Screen](#)

2



Click [FIRMWARE UPDATE]

3




Click [UPDATE]

**The message [Unable to get the update information of the firmware!!] is displayed.**

This product is in the latest state.  
There is no need to carry out the operation of this procedure.

4




Click [Yes]



The front indicator flashes.

5



Confirm that the front indicator is lit.






This completes the setting.

# 3. Details of the Settings screen


<a href="#">3.1. HOME</a>	<a href="#">30</a>
<a href="#">3.2. SYSTEM INFORMATION</a>	<a href="#">31</a>
<a href="#">3.3. SYSTEM SETTINGS</a>	<a href="#">33</a>
<a href="#">3.4. USB DEVICE SETTINGS</a>	<a href="#">38</a>
<a href="#">3.5. DISK MANAGEMENT</a>	<a href="#">39</a>
<a href="#">3.6. SYSTEM INITIALIZATION</a>	<a href="#">40</a>
<a href="#">3.7. FIRMWARE UPDATE</a>	<a href="#">41</a>

## 3.1. HOME




	<a href="#">3.2. SYSTEM INFORMATION (page 31)</a> is displayed.
	Turn off the power to this unit (shut down), and reboot.
Each item	<p>The page showing each item is displayed.</p> <p>&gt;&gt; <a href="#">3.3. SYSTEM SETTINGS</a> <span style="float: right;">33</span></p> <p>&gt;&gt; <a href="#">3.4. USB DEVICE SETTINGS</a> <span style="float: right;">38</span></p> <p>&gt;&gt; <a href="#">3.5. DISK MANAGEMENT</a> <span style="float: right;">39</span></p> <p>&gt;&gt; <a href="#">3.6. SYSTEM INITIALIZATION</a> <span style="float: right;">40</span></p> <p>&gt;&gt; <a href="#">3.7. FIRMWARE UPDATE</a> <span style="float: right;">41</span></p> <p>* On [MEDIA SERVER SETTINGS], you can make detailed settings for the Twonky Server. For details of this screen, please see "Twonky Server Reference" <a href="#">here</a>.</p> <p>The [ONLINE MANUAL] shows a Web page on which this document and others have been released.</p> <p>In [LANGUAGE SETTING], you can set the language of the Settings screen to either [Auto], [English] or [Japanese].</p>

## 3.2. SYSTEM INFORMATION

This is displayed if you click  in the HOME.

It shows various pieces of information about this unit such as its free space.



fldata HFAS1 series	
SYSTEM INFORMATION	
F/W version:	1.30 ( 16/04/06_12:43 )
IP address:	192.168.0.244
MAC address:	00:00:00:00:00:00
Internal disk capacity:	999.8GB (999,831,990,272byte)
Internal disk space:	989.1GB (989,094,162,432byte)
USB disk (for share) capacity:	8.1GB (8,053,026,816byte)
USB disk (for share) space:	8.0GB (8,023,553,216byte)
USB disk (for backup) capacity:	Unconnected
USB disk (for backup) space:	Unconnected
RAID mode:	Spanning
RAID status:	Started
Backup status:	Unconnected
USB-DAC device:	Unconnected

© I-O DATA DEVICE, INC.

### RAID status

Displays the status of this unit.

If an error such as [RAID starting failed] or [Degraded] is displayed in red, please reboot this unit once.

If you the same error is still displayed, please see the Quick Guide or contact our Support.

**Backup status**

Displays the status of the backup function.


Off	[AUTO BACKUP] ( <a href="#">3.3. SYSTEM SETTINGS (page 33)</a> ) is off.
Running	A USB HDD for backup is connected, and the system is in a state where backup is possible.
Running (currently backing up)	Music is being backed up to a USB HDD for backup.
Unconnected	A USB HDD for backup is not connected.
Stopping	A USB HDD for backup is connected, but is not being used. The following situations can be considered. <ul style="list-style-type: none"> <li>• It is not a USB HDD for backup that is registered in this unit.</li> <li>• After the USB HDD for backup was registered, this unit was formatted/initialized.</li> </ul>
Unknown	An unknown error occurred in the backup. Operation has become unstable for some reason. Please remove the USB HDD for backup and reboot this unit. <a href="#">&gt;&gt; 2.2.3. Removing the USB HDD</a> <span style="float: right;">8</span>
Error	An error occurred in the backup. The following situations can be considered. <ul style="list-style-type: none"> <li>• There is not enough space on the USB HDD for backup. Please see the Quick Guide, access the backup destination (bkup folder) from a computer, and delete any unnecessary files.</li> <li>• A USB HDD for backup is not correctly connected.</li> </ul>




## 3.3. SYSTEM SETTINGS

You can apply various settings to this unit.


Click the [+] symbol to see a detailed description of each item.




NAME	You can decide on a name for this unit. Please do not choose the same name as that used for other devices, and select an easy-to-understand one. If you want to revert to the default settings, please run [AUTO].
Name	You can decide on a name for this unit.
AUTO	Reverts to the name that was set at the time of purchase.




NETWORK	In the default settings, [DHCP], which is used to automatically obtain an IP address, is set to [On]. Please set it to [Off] if you cannot easily get an IP address in this setting, and manually enter the IP address. * If you switch DHCP from [Off] to [On], this unit will automatically reboot.
DHCP	Set whether to automatically obtain data such as an IP address from a DHCP server (Wi-Fi router, etc.).
IP address	
Subnet mask	When [DHCP] is [Off], set it manually.
Default gateway	Please set it according to the network environment.
DNS server	




TIME	You can Time Sync with a time server over the Internet. When performing Time Sync with a time server, set [Time Sync] to [On], and specify the URL of the time server in [Server URL].
Time Sync	Set whether to perform Time Sync with a time server over the Internet.
Server URL	When [Time Sync] is set to [On], specify the URL of the time server that will perform the Time Sync.
Time	When [Time Sync] is set to [Off], specify the date and time.
AUTO	Aligns to the time of the terminal on which the settings screen is open.
Time Zone	Specify the area in which you live, and set the standard time there.




FRONT INDICATOR	Specifies the brightness and color of this unit's front indicator.
Front Indicator Brightness	Specifies the brightness of the front indicator. When it is set to [Off], the indicator will not show a white light or green light. However, when you turn on the power or use the settings screen, the indicator lights up for only five seconds in order to show that the operation is complete (lights up after flashing).
Front Indicator Color	Specifies the color of the front indicator.




SHARED FOLDER	Specifies [On] or [Off] for the SHARED FOLDER. Please change the settings after confirming that no device is accessing the Shared Folder.
Shared Folder	When this is set to [Off], it is not possible to access the [Contents], [usb1] and [bkup] folders. Usually, you do not need to set this to [Off].




POWER SAVING	This specifies the time before the internal hard disk switches to power saving mode. In an SSD-equipped model, this setting will be [Off].
Setting Time	This unit is an SSD-equipped model, so this setting is [Off].




AUTO BACKUP	Specifies whether the Auto Backup function of the USB HDD is [On] or [Off]. By setting this to [On], data is regularly backed up to the registered USB device.
Auto Backup	When it is set to [On] and the system connects to the registered USB HDD, audio data is regularly backed up to the USB HDD.




AUTO UPDATE	Specifies whether the function to automatically update firmware is [On] or [Off]. If this unit is connected to the Internet and there is a firmware update, when this unit shuts down or reboots it will automatically update to the latest firmware.
Auto Update	When it is set to [On], when this unit shuts down or reboots and there is a firmware update, it will automatically update to the latest firmware. * This unit must be connected to the Internet for this function.




MEDIA SERVER	Specifies [On] or [Off] for the Twonky Server to be used as a media server.
Twonky Server	When it is set to [On], the media server [Twonky Server] publicly releases the saved audio data.




NETWORK RENDERER	<p>Set the operation mode during USB-DAC connection.</p> <p>In OpenHome mode, even if you stop the controller app, it can be the play of the playlist.</p> <p>OpenHome mode is available in the corresponding controller app.</p> <p>If you want to use the unsupported controller app to OpenHome, please set the DMR.</p>
Network Renderer	<p>Set it according to the controller app you use.</p> <p>This unit is set to [OpenHome] at the time of purchase. Therefore, if you are unable to operate this unit on your controller app, please try switching to [DMR].</p>




DoP	<p>When connecting to a USB-DAC that supports DoP (DSD Audio over PCM Frames), you can set whether or not to play music with DoP.</p> <p>When DoP is set to [On], you can use the DoP system to play back DSD content.</p> <p>When using a USB-DAC that does not support DoP, this is set to [Off].</p>
DoP	<p>This is set to [On] at the time of purchase, and you can use the DoP system to play back DSD content.</p> <p>When connecting a USB-DAC that does not support DoP, this is set to [Off].</p>



LAN SPEED	<p>You can set the upper limit setting of the link speed in the LAN port (1=for Audio / 2=for Network) of this unit, and switch Off the ports.</p> <p>You cannot set both LAN ports to [Off] at the same time.</p> <p>* When a setting is changed, this unit will automatically reboot.</p>
LAN port 1	<p>Set the upper limit value of the link speed of each LAN port.</p>
LAN port 2	<p>If you set it to [Off], the functions of that LAN port will be disabled.</p> <p>* You cannot set both LAN ports to [Off] at the same time.</p>




LAN PORT INDICATOR	Set the indicator above the LAN port, which is installed on the back of this unit, to [On] or [Off]. The [On] or [Off] setting here is applied to both the LAN port indicators. * You cannot set both LAN ports to [Off] at the same time.
LAN port Indicator	When it is set to [Off], both the indicators above the LAN ports, which are installed on the back of this unit, will not light up.




CONFIRM	Completes the setting, and goes to a screen where you can confirm what you have set on the screen. After confirmation, running [SET] will reflect the settings in the system.
---------	--

## 3.4. USB DEVICE SETTINGS



Registration of the device for backup	Register a connected USB HDD as one for backup use. <a href="#">&gt;&gt; 2.7.2. Registering the USB HDD as a backup one</a> <span style="float: right;">18</span>
Restoration of backup data	Returns backed up music to this unit. <a href="#">&gt;&gt; 2.7.3. Restoring Music from a USB HDD for Backup</a> <span style="float: right;">20</span>
Data import	Connect a USB HDD containing music to this unit with a computer or such like, and then copy the music to this unit. <a href="#">&gt;&gt; 2.2. Saving Audio Files from a USB HDD</a> <span style="float: right;">6</span>
Removal of the USB device	Removes a USB HDD for backup or a shared USB HDD. * When you connect a normal USB HDD, the USB HDD is shared. <a href="#">&gt;&gt; 2.2.3. Removing the USB HDD</a> <span style="float: right;">8</span> <a href="#">&gt;&gt; 2.3. Streaming Music on a USB HDD as it is</a> <span style="float: right;">10</span>

## 3.5. DISK MANAGEMENT




Check Disk	Checks the status of the built-in disk of this unit. Depending on the capacity and condition of this unit, [Check Disk] may take 20 or 30 hours. In addition, you cannot access this unit while [Check Disk] is running.
Spanning Format Striping Format Mirroring Format	Deletes all the data on this unit and switches the mode of the built-in disk. Depending on the capacity and condition of this unit, formatting may take 20 or 30 hours. In addition, you cannot access this unit while a disk is being formatted. <a href="#">&gt;&gt; 2.8. Switching the Mode of the Built-in Disk (RAID)</a> <span style="float: right;">22</span>

## 3.6. SYSTEM INITIALIZATION

Puts this unit back into the state it was in at the time of purchase.

Returns all the settings of this unit to the default value, and deletes data on this unit.




Regular format of internal disk	When this is set to [On], the data in this unit is completely deleted so that it cannot be restored.		
	Model	Normal initialization	Regular format
	1 TB / SSD	About 3 minutes	About 2 hours



## 3.7. FIRMWARE UPDATE

Update the firmware (internal software) of this unit, and keep it up to date.  
This unit must be connected to the Internet.



# 4. Troubleshooting

<a href="#">The front indicator is lit in orange.</a>	43
<a href="#">The front indicator is lit in red.</a>	43
<a href="#">I want to put this unit back into the state it was in at the time of purchase.</a>	43
<a href="#">Artwork is not displayed / has stopped being displayed.</a>	45
<a href="#">I want to see the music that was backed up on a computer.</a>	46
<a href="#">I cannot play music when I am using this unit as an audio player.</a>	46
<a href="#">This unit does not appear in Magical Finder.</a>	46

## The front indicator is lit in orange.

- **A new version of firmware/software for this unit has been detected.**

Please turn off the power supply to this unit, and then turn it on again.

This firmware/software for this unit will be updated to the latest version.

## The front indicator is lit in red.


- **It is possible that the USB HDD for backup does not have enough free space.**  
Please see the Quick Guide, access the USB HDD for backup from a computer, and delete any unnecessary files.
- **It is possible that a problem has occurred with the USB HDD for backup.**  
Please confirm whether the USB HDD for backup is correctly connected.  
If it is connected correctly, there is a possibility that the USB HDD has failed.  
In addition, please use this unit to format the USB HDD when connecting it for the first time.
- **It is possible that a problem has occurred with the internal disk of this unit.**  
Remove a USB HDD if it is connected.  
(>> [2.2.3. Removing the USB HDD](#) 8)  
Then, please turn off the power supply to this unit, and then turn it on again.  
After the start-up process has completed, if the lamp is lit in red then a problem has occurred with the built-in disk.  
Please see the "Conformity Information and Warranty", and contact our Support.

## I want to put this unit back into the state it was in at the time of purchase.

By initializing the system, you can return all the settings of this unit to those at the time of purchase, and delete data on this unit.


### 1 [2.1. Open the Settings Screen](#)

2



Click [SYSTEM INITIALIZATION]

3



### [Regular format of internal disk]


When this is set to [On], the data in this unit is completely deleted so that it cannot be restored.

Data will be written to all parts of the built-in disk, and so it will take a very long time.

(For a guide to the time required, please see [here \(page 40\).](#))


Click [RUN].

4



Click [Yes]

5



Click [Yes]

↓  
System initialization begins.

↓  
The front indicator flashes.

↓  
Confirm that the front indicator is lit.

↓  
This completes the operation.

## Artwork is not displayed / has stopped being displayed.


- From version 1.10 of this unit, the default setting for artwork has changed to high image quality.

Therefore, if you are using an audio device that does not support high-quality artwork, you may find that artwork is not displayed.

Please try the following actions.


### 1 [2.1. Open the Settings Screen](#)

2




Click [MEDIA SERVER SETTINGS]

3



Click [Sharing]

4



Click [Show], and show the contents of the media receiver.

Set the [Media Receiver Type] of an audio device that does not show artwork to [Generic Media Receiver (BC)].

Click [Save Changes]

### How to tell which audio device does not show artwork.

The list shows the [MAC] (MAC address), [IP] (IP address), and [Friendly Name] of the audio device. Please confirm these details of the audio device.

You can confirm the MAC address on a sticker that is attached to the audio device or on its Settings screen.

### I want to see the music that was backed up on a computer.

- **You can see it on [LAN DISK Backup Reader].**  
For details, please visit our web page (in English).  
<http://www.iodata.jp/fidata/en/support/#download>

### I cannot play music when I am using this unit as an audio player.

- **The type of controller app does not match the [NETWORK RENDERER].**  
Please open the Settings screen, and switch the [NETWORK RENDERER] settings ([page 36](#)).

### This unit does not appear in Magical Finder.

- **The computer or smart device running Magical Finder is not on the same network as this unit.**  
Please connect the computer or smart device to the same Wi-Fi router as this unit.